



Seed Starting Grow Light

Assembly Instructions

Light Stand Parts List


- 2 – Vertical Leg Bars
- 2 – Foot Bars
- 1 – Channel Crossbar with Cord & Lock
- 1 – Grounded Power Cord with On/Off Switch
- 1 – Allen Wrench
- 2 – Screws

Lamp Fixture Parts List

- 1 – 24" or 48" T5 Lamp Fixture
- 1 – 24" or 48" T5 HO Fluorescent Tube
- 2 – Hook-Style Hanging Clips

Constructing the Light Stand

1. Install the foot bars into the vertical leg bars. Make sure that the foot bars sit flush against the vertical leg bars. Secure the foot bars to the vertical leg bars using the Allen Wrench and the screws provided.
2. Set the top crossbar on a sturdy, flat surface with the holes facing up. Slide the open ends of the leg bars into the holes of the crossbar. Make sure that the leg bars are seated firmly into the crossbar.
3. Return light stand to upright position. We recommend positioning it over a chair or other elevated surface in preparation for mounting the lamp fixture to the light stand.



Mounting The T5 Lamp Fixture to the Light Stand

1. Carefully unpack components from box and remove protective foam.
2. Inspect the fixture, hanging clips and T5 fluorescent tube for any damages. If present, please contact your vendor for service and replacement.
3. To remove the T5 fluorescent tube, hold the metal ends of the T5 fluorescent tube and carefully rotate the T5 fluorescent tube 90° in either clockwise or counterclockwise motion. Once the tube becomes loose from the socket, remove the T5 fluorescent tube and slide the padding supports off both ends of the tube and then put tube back in place.
4. Attach the hanging clips to the back of the fixture. The mounting position is indicated by black arrows.
5. Set the lamp fixture under the crossbar as shown in the figure on the left and pull down the hanger cables.
6. Slide the rings from the ends of the cables into the hanging clips of the fixture.
7. You may adjust the height of the lamp fixture by adjusting the length of cord at the center of the crossbar, and set the height by securing the locking mechanism against the crossbar.
8. Plug the grounded power cord (provided) into the wall socket.

CAUTION

- Do not use with dimmers, dimming switches or any power potentiometers.
- Do not connect multiple light systems.
- Mechanical, analog and digital timers supported.

#4893 Seed Starting Grow Light 24"

#4895 Seed Starting Grow Light 48"

Manufactured for:
Gardens Alive!, Inc.
4424 Dixie Highway
Fairfield, OH 45014
513-354-1483
www.GardensAlive.com